## **ASSEMBLY INSTRUCTIONS** 24 INCH BATH VANITY (COMBO) O Ø 97 $q_7$ Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present. "DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED" **Tools Required** Use of power tool to assemble this product will invalidate any claim and Œ damage this product making unsafe !!! Please assemble on a clean soft surface to avoid damage. ≥ ∦ (Not included) (Not included) **IMPORTANT:** PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY 1

# **Before Installation**

#### Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.

- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.

. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.



#### **Cam Lock Assembly Instructions**



























# HINGE ADJUSTMENTS



## Sideways / Tilt adjustment

Turn the screw

**clockwise** to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet



## 2 4 Height adjustment

While supporting the weight of the door, turn the screws **clockwise** to move the door up

anticlockwise to move the door down



If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw clockwise to decrease the gap between the door and the cabinet anticlockwise to increase the gap between the door and the cabinet



