


# THE MYKONOS 52" & 60" CEILING FAN INSTALLATION INSTRUCTIONS

---

Please read and save these instructions



---

**These instructions are to be used in  
the installation of the following  
QUORUM INTERNATIONAL fans...**

The Mykonos 52" & 60"

**Q**UORUM  
INTERNATIONAL

© 2018 Quorum International. All Rights Reserved.

# QUORUM'S UNIQUE LIMITED LIFETIME WARRANTY

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**WHAT IS COVERED-**

Except as specified below, the manufacturer of this product warrants it to be free of all defects in workmanship and material.

**WHAT IS NOT COVERED BY THIS WARRANTY-**

- 1. All costs of removal or reinstallation of the fan.
- 2. Damage resulting from failure to follow instructions contained herein.
- 3. Damage occurring during shipment of the product (claims must be presented to the carrier).
- 4. Damage resulting from accident, misuse, abuse, or neglect.
- 5. Damage resulting from the application of any exterior coating, or by the addition of any unapproved accessories.
- 6. Damage resulting from repair or attempted repair by anyone other than the manufacturer.
- 7. Damage resulting from causes other than product defects, including lack of

technical skill, competence, or experience of the user.

- 8. Light bulbs, glass or acrylic components or accessories.
- 9. Minor occurrences of wobble are accepted as normal and should not necessarily be considered a defect.

**WHO MAY ENFORCE WARRANTY-**  
This warranty may be enforced only by the original purchaser. The end user must possess a dated proof of purchase from an authorized Quorum dealer to establish a warranty claim.

**LENGTH OF THE WARRANTY -**

- 1. For the fan motor - for the lifetime of the original purchaser.
- 2. For everything else, except blades and finish - one year from the date of purchase.
- 3. For fan blades and finish - 90 days from the date of purchase.

**WHAT WE WILL PAY FOR -**  
We agree to correct defects outlined in the warranty without charge, or at our option replace the fan with an equivalent or

superior product if the defective unit is returned prepaid to us.

**TO GET WARRANTY SERVICE -**  
To obtain warranty service, the product must be returned prepaid to Quorum. (This warranty is not enforceable outside the United States.) Details regarding return shipment are explained elsewhere in this manual. Whenever warranty service is required, *you must present a copy of the original dated sales receipt as proof of coverage.*

*There is no other express warranty. Quorum hereby disclaims any and all implied warranties, including but not limited to those of merchantability of fitness for a particular purpose to the extent permitted by law. Quorum shall not be liable for incidental, consequential, or special damages arising out of or in connection with the product use or performance except as may otherwise be accorded by law. The duration of any implied warranty which cannot be disclaimed is limited to the periods specified above in the express warranty.*

## WARRANTY SERVICE

- 1. Most problems can be handled by our customer service agents over the telephone. Customers seeking warranty repair or replacement for any fan or component are encouraged to call us for assistance. All returns must be issued a Return Goods Authorization number (RGA) prior to returning the defective unit or part. Call (817) 626-5483 - Monday thru Friday 8:00 a.m. - 5:00 p.m. CST to obtain a RGA number.
- 2. Arriving shipments will be refused if they do not bear a valid RGA number on the outside packaging.

- 3. A dated proof of purchase must accompany any fan or component clearly indicating the name of the original purchaser.
- 4. To avoid damage in transit, the product should be returned in its original box and packaging. Quorum will not bear responsibility for any shipping damage.
- 5. Any return of a fan or component must be shipped freight and insurance prepaid.

**FOR YOUR RECORDS**

Purchased From \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_

Fan Model No. \_\_\_\_\_

Date Purchased \_\_\_\_\_

**Complete and mail the enclosed warranty card within 10 days to ensure your warranty is registered.**

**If you have any questions regarding the warranty, or the procedures for obtaining service, please call us at (817) 626-5483 - Monday thru Friday 8:00 a.m. - 5:00 p.m. CST.**

# 1. SAFETY RULES

Models #65210-xx: 35.94 lbs  
66010-xx: 39.46 lbs

**1.** To avoid possible electric shock, **turn off the electricity** at the main fuse box or circuit panel before you begin the fan installation or before servicing the fan or installing accessories.

**2.** Read all instructions and safety information carefully before installing your fan and **save these instructions**.

**3.** Make sure all electrical connections comply with local codes or ordinances as well as the National Electrical Code. If you are unfamiliar with electric wiring, please use a qualified and licensed electrician.

**4.** Make sure you have a location selected for your fan which allows clear space for the blades to rotate, and at least seven (7) feet of clearance between the floor and the fan blade tips.

**5.** The support structure must be securely mounted and capable of reliably supporting a minimum of 50 pounds (22.7 kg).

**6. WARNING- Support Directly from the Building Structure.**

**7.** To reduce the risk of personal injury use only approved hanging brackets and screws supplied with the outlet box for mounting to the outlet box.

**8.** After installation is complete, check that all connections are absolutely secure.

**9.** Do not insert anything into the fan blades while they are rotating.

**10.** To operate the reverse function on the fan, press the reverse button on the wall transmitter while the fan is running.

**11.** Do not attempt to control the operation of the fan (or an optional light kit) from any wall control that is not approved by Quorum for use with its fans. Do not use solid state wall controls. The use of any unapproved control voids the fan's warranty.

## TOOLS REQUIRED FOR INSTALLATION


Phillips Screwdriver  
Wire Cutters  
Electrical Tape  
Step Ladder

# 2. UNPACKING YOUR FAN

Unpack your fan and check the contents. Do not discard the carton. If warranty replacement or repair is ever necessary the fan should be returned in original packaging. Remove all parts and hardware. Do not lay motor housing on its side - because the decorative casing may shift. Check all visible screws, bolts and nuts for tightness. Examine all parts. The following parts should be included:

**NOTE:**

Some Quorum fan models will have slightly different parts than what is shown here depending upon the design you have chosen. Basic installation procedures are similar for all models.



1. Set of blades (a)
2. Decorative rods (b)
3. Hanger bracket plate (c)
4. Hanger bracket (d)
5. Canopy (e)
6. Canopy cover (f)
7. 8" Downrod assembly (g)
8. Yoke cover (h)
9. Fan motor assembly (i)
10. Decorative rod support plate (j)
11. Control cup plate (k)
12. Control cup (l)
13. Wall transmitter incl. 2 mounting screws and 3 wire nuts (m)
14. 2 wall plates (white and almond), 1 face plate (almond), 2 sets of mounting screws, and machine screws (n)
15. Battery (o)
16. Parts bags containing (p)
  - Mounting hardware  
(2 #14x3.5" wood screws, 2 star washers, 2 metal washers, 1 #12x3" wood screw, 1 metal washer, 3 wire nuts,)
  - Decorative rod attachment hardware  
(21 5/32 x 19mm Screws)
  - Blade attachment hardware  
(21 3/16 x 24mm Screws)
  - 10 Decorative rod mounting nuts

IF YOU FIND THAT PARTS ARE MISSING. CONTACT YOUR DEALER FOR REPLACEMENT, OR CALL QUORUM DIRECTLY AND WE WILL MAIL REPLACEMENTS TO YOU IMMEDIATELY.




# 3. MOUNTING OPTIONS

1. Disconnect the power by removing fuses or turning off circuit breakers.
2. The support structure must be securely mounted and capable of reliably supporting a minimum of 50 pounds (22.7 kg).

**WARNING:** Support Directly from the Building Structure.

3. Secure the outlet box (or make sure the existing box is secured) directly to the building structure. Use appropriate fasteners and building materials.
4. Figures 1,2 and 3 are examples of different ways to mount the outlet box in different situations. A longer downrod may be required in sloped ceiling situations to maintain proper blade clearance. Fan will mount at 25 degrees maximum with minimum 8" downrod (Fig. 3)

**CAUTION:** DO NOT USE WITH SLOPE CEILING ADAPTER ACCESSORY.



# 4. HANGING YOUR FAN

**WARNING** -Turn off the power!

1. Remove the motor top housing and metal washer by remove the six screws with lock washers from the motor collar. (Fig. 4)

2. Insert the blade assembly through the slot in the motor housing. Carefully insert blade to blade arm on top of the motor. Align the holes in the blade and the fan motor assembly and secure with 2 screw provided. Tighten screws securely. (Fig. 5)

3. Place the motor top housing over the motor. Align the mounting holes with the holes in the motor and fasten using the six screws with lock washers and metal washer previously removed.(Fig. 5)

4. Remove two knock-outs from the outlet box to expose the joist. Use the two wood screws and washers provided to secure the hanger bracket plate directly to the building joist via the knockout holes from the outlet box. (Fig. 6)

**CAUTION: The hanger bracket plate must be installed directly to the building joist using the two wood screws and washers provided.**

5. Secure hanger bracket to hanger bracket plate using the two hex nuts and washers provided, make sure nuts are securely tighten. (Fig. 7)

Fig. 4




Fig. 6




Fig. 5





Fig. 7



# 4. HANGING YOUR FAN (continued)

**WARNING** -Turn off the power!

1. (Fig. 8) Remove the set pin and safety lock clip from the yoke on top of the motor assembly. Slide the downrod through the canopy and canopy cover. Slide the yoke cover onto the downrod.

2. (Fig. 9) Attach the downrod assembly (downrod, yoke cover, canopy and canopy cover) to the motor by sliding the downrod into the yoke on top of the motor assembly. Slide the set pin through the hole in the yoke, downrod and secure it with the safety lock clip. Tighten the set screws on yoke. The yoke cover will lower down to conceal the yoke. Feed the safety cable and wires through the downrod assembly.

3. (Fig. 10) Lift the fan motor and place into the hanger bracket, rotating the ball until the groove engages the tab on the hanger bracket. This locks the ball mount and fan motor, preventing fan rotation during operation.

4. (Fig. 10) An additional safety support is provided to prevent the fan from falling. Secure the safety cable to the ceiling joist with screw and washer, as illustrated in Figure 10.

Fig. 8




Fig. 9





Fig. 10



# 5. ELECTRICAL CONNECTIONS

**REMEMBER** -Turn off the power! **NOTE** - Control must be installed within 30 feet of fan.

Use the wire nuts supplied with your fan when making connections. Secure the connectors with electrical tape and make sure there are no loose connections or wire strands.

1. Spread the wires apart so that the black wire from the fan is on one side of the mounting bracket and the white wire and green ground wire are on the other side.

2. (Fig. 11) Connect the BLACK building supply wire to the BLACK fan wire. Connect the WHITE building neutral wire to the WHITE fan neutral wire. Connect the COPPER building ground wire to the GREEN fan ground wire.

3. Inside the ceiling junction box be sure to spread the wires apart so that the black connection is on one side of the outlet box and the white/white and green/copper connections are on the other side.

4. Connect the wiring from the wall switch receptacle to wall transmitter unit.


- Remove the existing wall plate and switch from the wall junction box.
- Connect the BLACK switch leg (wire from wall receptacle to outlet box) from the wall to the BLACK wire (labeled "TO FAN") from the wall transmitter.
- Connect the other BLACK wire (labeled "TO POWER SUPPLY") from the transmitter to the remaining BLACK wire from the wall (A/C supply source).

- If your junction box has a ground wire (green or bare copper), connect the transmitter's ground wire to it. Otherwise, connect the transmitter ground wire directly to one of the screws from the outlet box.

- Carefully tuck the connected wires inside the junction box. Secure the transmitter with the two screws provided. Attach the face plate over the transmitter with the two screws provided.

Use **ONLY** wall controls approved by Quorum. Use of unapproved wall controls will cause unacceptable humming noise, and avoids the fan warranty.

Fig. 11






# 6. COMPLETING THE INSTALLATION

1. Make sure the wiring is safely inside the outlet box as instructed in **Step 5 - Electrical Connections**.

To install the canopy, slide the canopy up to hanger bracket and place the key hole on the canopy over the screw on the hanger bracket, turn canopy until it locks in place at the narrow section of the key holes. (Fig. 12) Align the circular hole on canopy with the remaining hole on the hanger bracket, secure by tightening the two set screws, lift canopy cover and attach by turning clockwise. **Note:** Adjust the canopy screws as necessary until the canopy and canopy cover are snug. (Fig. 12)

Fig. 12



## 2. Installing the Decorative rods

Remove decorative rod nut from blade end and slide the decorative rod onto the blade end screw. Attach the decorative rod nut loosely - do not tighten at this time (Fig. 13). Align the opposing end of the rod with holes in the decorative rod holder and attach screw by passing through the rod to attach to the outer hole in the decorative rod holder and tighten (Fig. 14). Be sure the other screw hole in the rod aligns with the inside hole in the decorative rod holder as it will be used later. Repeat process for all other rods. Once completed, tighten the decorative rod nuts on end of blades.

Fig. 13




Fig. 14




Fig. 15




Fig. 16





Fig. 17



## 3. Installing the Decorative Rod Support plate

Place the decorative rod support plate up to the motor. Align holes from the support plate and rod and secure with the ten decorative rod screw in inner holes. Make sure all screws are tightened securely. (Fig. 15)

## 4. Attaching the Control Cup Plate

Attach the control cup plate to the flange of the motor by using the three screws provided that are pre-installed on the flange. (Fig. 16)

## 5. Attaching the Control Cup

Snap together the cannon plugs, attach the control cup to the control cup plate with the three screws provided. (Fig. 17)

# 7. INSTALLING THE WALL CONTROL


**REMEMBER** -Turn off the power! **NOTE** - Control must be installed within 30 feet of fan.

1. Remove the existing wall plate and switch from the wall junction box.

2. If your outlet box has a ground wire (green or bare copper) connect the wall control's ground wire to it; otherwise connect the wall control's ground wire directly to one of the screws from the outlet box.

3. (Fig. 18) Carefully tuck the wire connections inside the junction box. Secure the wall control with the two screws provided. Attach the wall plate over the wall control and secure with the two screws provided.

Fig. 18



# 8. OPERATING YOUR TRANSMITTER

Your DC brushless motor is equipped with an automatically learned type remote control. There are no frequency switches on the receiver; the receiver unit will automatically scan the frequency from the wall control. The fan can start to use once the control setting process is done.

Remove the panel from the transmitter and then install one 23A/12V battery (included). To prevent damage to transmitter, remove the battery if not use for long periods of time (Fig. 19).

A. I, II, III, IV, V and VI buttons: These six buttons are used to set the fan speed as follows:

- I = minimum speed
- II = low speed
- III = medium low speed
- IV = medium speed
- V = medium high speed
- VI = high speed

B. ■ button: This button turns the fan off.

C. ↺ Reverse button: This button is to control fan direction. This button must be pressed while fan is running (suggested speed IV).

D. ☀ Light button: This button is to control light. Switch the "D" and "ON" dip switch on the front of transmitter to decide the light in "ON/OFF" or "Dimmable" condition.

E. "D" and "ON" dip switch:

The "ON" selection is the light dimmable selection. The "D" selection is for light on/off only (non dimming function)

F. "SET" code setting button:

Follow the below steps to use the set button. (Fig. 19)

G. ON - OFF Slide button: Power switch. (Fig. 20)

H. Signal light (Fig. 20)

## Pairing Process

With the fan's power off, restore power to the fan. Press and hold "SET" button for about 5 seconds and release. If optional light kit is installed, the light kit will flash twice and the signal light on the wall control will come on when the button is pressed. The fan has completed the pairing process with the wall control and is ready for use.

Fig. 19





Fig. 20



## 8. OPERATING YOUR TRANSMITTER (continued)

If a room has two fans installed, each fan will need it's own wall control. A single control CAN NOT control more than one fan. Each fan will need to go through the pairing process individually. While running the pairing process on the first fan, turn power off to the second fan. When finished the pairing process for the first fan, turn the power off and restore power to the second fan and run the pairing process- NOTE the "SET" button must be pressed within 60 seconds of restoring power to the second fan.

**NOTE:** If multiple fans are installed on the same circuit, each fan must have it's own switch leg. Each fan and wall control pair must have its own wire from the control to the fan(the wire from the control to the fan can NOT be shared). There can NOT be a jumper wire running from fan to fan.

**NOTE:** The "SET" button must be pressed within 60 seconds of restoring power.

**The receiver provides the following protective function:**

1. **Lock position:** The DC motor has a built-in safety against obstruction during operation. The motor will be locked operation and disconnect power after 30 seconds of interruption. Please remove obstacles before re-set.
2. **Over 80W protection:** When the receiver detects motor power consumption which is greater than 80W, the receiver power will be stopped and operation will immediately discontinue. Turn the receiver power on after 5 seconds.

## 9. FAN OPERATION AND CARE

1. A ceiling fan is an environmentally smart choice to cool as well as to help warm your home or office. Adjust your HVAC thermostat during fan use to save additional energy and money on your air conditioning and heating utility bills. You should see a significant reduction in both your heating and cooling costs by regular use of your fan.

Do not hesitate to use your fan during summer and winter months. In summer, (Fig. 21) using the reverse switch, adjust the fan's direction so cool air is blown down, producing a cooling breeze. In winter, (Fig. 22) reverse the fan so that an upward airflow will push warm air off the ceiling and circulate it downwards into the living area. In winter months, use the fan at a lower speed than summer.

2. Periodically check tightness of all screws securing the blades to the blade arm attachment points. A clicking or a rattling noise is a sure indication of loosening screws. Since screws will invariably work loose over time, at least once a year, tighten all the screws attaching blades to blade arms. **Do not bend blade arms when cleaning or servicing the fan.**

3. Clean you fan periodically using only a cloth dampened with a mild detergent solution for all hardware - never use solvents. The finish plating is lacquered to prevent tarnishing. Use duster to clean the canvas blades.

4. You will never need to oil or lubricate your fan. Its permanently sealed bearings will provide trouble free, silent operation for many years.

5. If repairs or servicing are ever required, to avoid possible electric shock, **turn off the electricity** at the main fuse or circuit panel before you begin.

Fig. 21





Fig. 22



# 10. TROUBLESHOOTING

## FAN WILL NOT START

1. Check that the electricity has been turned on at the circuit breaker which had probably been turned off during installation.

2. Turn off the electricity. Check all connections in the wiring of the fan at the ceiling and make sure it follows the wiring instructions outlined in this manual.

3. Be sure ON/OFF power switch on the wall control is in ON position.

4. Be sure the wall control is installed within 30 feet of ceiling fan.

## NOISE

**Note:** Always allow a day or two "run-in" time for any new fan at medium or high speed. When attempting to diagnose noise, listen carefully from several sides to try and isolate the location of the noise (blade, upper end, motor, light kit, etc.)

1. Tighten all screws attaching blades to motor. Remember to tighten these screws at least once a year because they may loosen slowly over time and cause a clicking noise.

2. Turn off the power. Loosen the canopy and check that the wiring and/or wire nut connectors are not resting against the canopy, possibly vibrating while the fan is on.

3. Use of a standard light rheostat or an unapproved fan wall control to control the fan speed will always cause an annoying "hum". Many fan motors do not work quietly with solid state variable speed controls.

4. Check that the rubber gasket on the mounting bracket has been installed if called for in the installation instructions.

5. Check that the canopy is not touching the ceiling.

## FAN TURNS, BUT DOES NOT MOVE MUCH AIR

1. The fan may be running in reverse. Press the reverse button on transmitter to set the fan in forward operation.

2. The distance from the ceiling to the blades may be too small. For downrod fans, optimal placement would be 8-9 feet from the floor.

3. The room may contain items which obstruct the air flow.

4. The fan may be too small for the size of the room.

## EXCESSIVE WOBBLE

**Note:** A small amount of wobble is considered acceptable and should not be considered a defect.

1. Make certain all blades are tightly attached to each blades' respective blade arm.

## REPLACEMENT PARTS

For replacement parts, contact your local dealer.