
SHADE 32247SHRAT (REPLACEMENT PART) GLASS DOME HPYBULBSHIELD (REPLACEMENT PART)



AVAILABLE PARTS ARE: 32247SHRAT (SHADE) HPYBULBSHIELD (GLASS DOME)



READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS LAMP SHOULD TAKE APPROXIMATELY 10 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

<u>WARNING:</u> WHEN USING FOR OUTDOOR USE, FOLLOW IMPORTANT SAFETY INSTRUCTIONS LISTED AT BOTTOM OF PAGE TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, AND PERSONAL INJURY.

IMPORTANT NOTE:

THIS LAMP CAN'T BE USED AT THE PLACE WITH STAGNANT WATER, PLEASE PLACE THIS LAMP ON A FLAT TABLE.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: LAMP BODY AND GLASS DOME. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

- 1. REMOVE THE COVER FROM TOP OF CAGE.
- 2. TAKE OUT OF THE SHADE FROM CAGE, THEN REMOVE THE PLASTIC BAG FROM THE SHADE.
- 3. INSTALL A 100 WATT MAXIMUM MEDIUM BASE TYPE "A" BULB (NOT INCLUDED) INTO SOCKET.
- 4. SCREW GLASS DOME TO THE GLASS DOME HOLDER.
- 5. SLIDE THE SHADE INTO THE CAGE.
- 6. PLACE THE COVER ONTO TOP OF THE CAGE AND PRESS THE COVER TO SECURE.
- 7. PLUG THE POWER CORD INTO AN OUTLET AND TURN ON AT SWITCH.

BULB REPLACEMENT

- 1. BEFORE REPLACING THE BULB, BE SURE THAT THE GLASS DOME AND BULB ARE COOL AND LAMP IS UNPLUGGED.
- 2. REMOVE THE COVER FROM TOP OF CAGE.
- 3. UNSCREW GLASS DOME AND EXISTING BULB, REPLACE WITH A NEW BULB AND RECOVER THE GLASS DOME.
- 4. PLACE THE COVER ONTO TOP OF THE CAGE AND PRESS THE COVER TO SECURE, PLUG POWER SUPPLY CORD BACK INTO OUTLET.

TROUBLE SHOOTING

- 1. IF YOUR LAMP DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.
- 2. IF LAMP STILL DOES NOT LIGHT, UNPLUG FROM OUTLET. CHECK THE BULB FOR A BROKEN FILAMENT. REPLACE BULB IF NECESSARY, PLUG IN LAMP AND TURN IT ON.
- 3. IF THE LAMP STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

IMPORTANT SAFETY INSTRUCTIONS

- 1. USE ONLY THREE—WIRE OUTDOOR EXTENSION CORDS THAT HAVE THREE—PRONG GROUNDING PLUGS AND GROUNDING RECEPTACLES THAT ACCEPT THE APPLIANCE'S PLUG.
- 2. GROUND FAULT CIRCUIT INTERRUPTER (GFCI) PROTECTION IS TO BE PROVIDED ON THE CIRCUIT OR OUTLET TO BE USED FOR THE WET LOCATION PORTABLE LUMINAIRE. RECEPTACLES ARE AVAILABLE HAVING BUILT—IN GFCI PROTECTION AND ARE ABLE TO BE USED FOR THIS MEASURE FOR THIS MEASURE OR SAFETY.
- 3. USE ONLY WITH AN EXTENSION CORD FOR OUTDOOR USE. SUCH AS AN EXTENSION CORD OF CORD TYPE SW, SW-A. SOW, SOW-A, STW, STW-A, STOW, STOW-A, SJW, SJW-A, SJOW, SJOW-A, SJTW, SJTW-A, OR SJTOW, SJTOW-A.



12/2012

32247RAT INSTRUCTIONS