WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE& IMPORTANT SAFETY INSTRUCTIONS

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this lamp cannot be replaced; If the cord is damaged, the lamp shall be destroyed


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Lamp base		1X	E	Harp		1X
В	Neck		1X	F	Shade		1X
С	Saddle		1X	G	Finial		1X
D	Socket		1X	Н	Bulb		1X



Model# JYL5056

Product Dimensions: 15.5"LX15.5WX19.5"H



^{**}This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. do not attempt to disgard this safety feature.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 6 minutes.

If there are any questions relating to defects, missing parts, assembly issues, replacements, or device connectivity issues, please send a detailed email to cs@jonathany.com


PLEASE USE ON/OFF TYPE"A" BULB MAX 60-WATT OR LED BULB MAX 9-WATT THERE IS LED 5-WATT BULB IN THE BOX








Step 1
Be careful not to twist the power cord and tighten securely.
Overturn the shade, make the metal ring on the inside.



Step2
Insert the Harp (E) into the Saddle (C).
Put the shade(F) on the Harp(E), then tighten the Finial (G)into the Harp (E)

Insert the bulb(H) into the socket(D).



Step 3
Put the light on a level surface to check if everything is stable.