

KITCHEN FAUCET MODEL: COS-KF222C

COSMO

Thank You





Thank you for your purchase. We know that you have many brands and products to choose from and we are honored to know that you have decided to take one of our products into your home and hope that you enjoy it.

Our faucets are designed according to the strictest performance standards for the North American market. We follow the most advanced manufacturing philosophy. Each faucet leaves the factory after thorough quality inspection and testing. Our distributors and our service partners are ready to answer any questions you may have regarding how to install, use and care for your faucet.

We hope that this manual will help you learn to use the product in the safest and most effective manner and care for it so that it may give you the highest satisfaction for years to come. If you have any questions or concerns, please contact the dealer from whom you purchased it, or contact our Customer Support at 1-888-784-3108.

The manual also includes directions for the professional installer that will install the product in your home. We recommend using trained personnel for professional installation.

Please keep this manual for future use

PRE-INSTALLATION INSTRUCTIONS

2

Plumber's putty



Pipe tape



Bucket



Philips Screwdriver



Pliers



Adjustable wrench

Make sure you have all necessary parts by checking the diagram and parts list. If any part is missing or damaged, please contact Cosmo Appliances at **1-888-784-3108**

Pre-drilled hole size requirement: 1-3/8" - 1-1/2"

Max countertop thickness without deck plate: 1-3/8"

Turn off the hot and cold water supply at the angle stops and turn on the old faucet to release any built up pressure. Remove existing faucet. Clean the sink of countertop to remove and debris, plumber's putty, and silicone.


Place a bucket under the angle stops. Turn on to clear any debris prior to installing new plumbing. Shut off angle stops.



TABLE OF CONTENTS

PARTS DIAGRAM ————————————————————————————————————	04
PARTS INCLUDED —	05
FAUCET DIMENSIONS —	06
INSTALLATION PROCEDURES ————————————————————————————————————	08
OPERATING INSTRUCTIONS ————————————————————————————————————	11
TROUBLESHOOTING —	12


FAUCET PARTS DIAGRAM



NO.	NAME	QTY
29	Lock Nut	1
28	Washer	1
27	Shank	1
26	Silicone Ring	1
25	Metal Ring	1
24	Handle	1
23	Screw	1
22	Handle Base	1
21	Trim Cap	1
20	Cartridge Nut	1
19	Cartridge	1
18	Body	1
17	Spout Assembly	1
16	O-ring	4
15	Spout Cover	1
14	Aerator	1
13	Gasket	1
12	Spout Handle	1
11	Screw	1
10	Spout Base Handle	1
9	Spout Cartridge	1
8	Spout Body	1
7	Connector	1
6	Screw	1
5	Spring	1
4	Spring cover	1
3	Hose	1
2	Bracket	1
1	Sprayer	1
_		



PARTS INCLUDED:














FAUCET DIMENSIONS



6




The minimum distance between the faucet hole and the wall should be 3.5". This is to ensure that the faucet lever can move freely allowing for full operation.



If the distance between the faucet hole and the wall is less than 3.5", you may position the faucet lever 30 degrees to 90 degrees off of the wall to allow for full operation


INSTALLATION PROCEDURE


Insert faucet through the top hole of installation site. Attach Plastic Holder (A), Silicone Ring (B), Metal Ring (C) under the faucet. Use the Nut (D) provided to hold sink and hardware into place. Once tightened, use the Screws (E) located on the nut to firmly secure into place.



Connect spray hose (B) to supply hose (A).

Connect the hot and cold hoses to the hold and cold hoses of the faucet. Hoses on the faucet are labeled.






Connect and tighten waterlines to hot and cold water supply (use plumbers tape on the water supply threads). Turn on the water supply and check for leaks (DO NOT TURN FAUCET ON K7Ffž

If no leaks are found turn the faucet on for 60 seconds to clear any debris from the water lines.

Usage

How to Operate the Handle



90°
RIGHT
HOT WATER

- 1. Pull the lever to the right to turn on the water. Push to the left to turn off
- 2. Pull the lever forward (towards you) to increase cold water flow and push the lever back (away from you) to increase the hot water flow.

Troubleshooting

If you have followed the instructions carefully and your faucet still does not work properly, take the following corrective steps:

PROBLEM	CAUSE	ACTION
Leakage under the handle.	Locking nut has come loose .	Unscrew the lever on the handle by hand. Loosen set screw with a hex wrench (2.5 mm). Remove the handle and unscrew cartridge cover by hand. Tighten locking nut with an adjustable wrench
Water will not shut off completely	Cartridge needs to be replaced.	Unscrew the lever on the handle by hand. Loosen set screw with a hex wrench (2.5 mm). Remove the handle and unscrew cartridge cover by hand. Unscrew the locking nut with an adjustable wrench. Replace ceramic disc cartridge.
Leaking between spray head and the hose (Spray head may be loose or washer is not seated correctly in the hose connection	Tighten the spray head by hand until snug. Make sure the washer is seated correctly

Codes/Standards Applicable:





HELP LINE

Our customer service hours are Monday – Friday, 10am – 5pm PST. Be sure to visit our website at www.cosmoappliances.com

If you are a homeowner please contact a Cosmo Appliances Service Representative at: 1-888-784-3108

In requesting warranty service, please be ready to provide:

- 1. Proof of purchase.
- 2. A description of the problem.



For full warranty details on this product please visit: http://www.cosmoappliances.com/warranty