Lima LED Ultra Shower Set Oil Rubbed Bronze Finish

Refer to the Assembly Video

Before you begin, read the installation instructions below. Observe all local building and safety codes.

Inspect and Repair the existing drywall, Floor Pan/Tile Backing, Studs and Joists Ensure that the Floor Pan is properly supported and that the drain is secure.

Determine the Location of the Shower Valve, Showerhead, Handheld Shower, and Body Sprays Mark the wall studs and plan the placement of the valve and fixtures.

Rough-In Plumbing Install the shower valve body and connect the water supply lines. Ensure that the valve is positioned correctly for the desired water temperature and flow.

Install the Showerhead and Handheld Shower Attach the showerhead and handheld shower to the wall, ensuring they are at the desired height and angle.

Install the Body Sprays Position and install the body sprays according to your preference.

Connect the Water Supply Lines Connect the hot and cold water supply lines to the shower valve. Use appropriate fittings and ensure all connections are tight and leak-free.

Test the Water Flow and Temperature Turn on the water supply and test the flow and temperature of each fixture. Adjust the valve as needed to achieve the desired water temperature and flow rate.

Check for Leaks Inspect all connections for leaks. Tighten any fittings that are leaking.

Install the Trim Plate Attach the trim plate to the shower valve body, ensuring it is flush with the wall.

Install the Handles Attach the handles to the valve stems and secure them with the provided screws.

Final Inspection Perform a final inspection to ensure all components are functioning correctly and there are no leaks.

Clean Up Remove any debris and clean the area around the shower.

Maintenance Tips Regularly clean the showerheads and body sprays to prevent mineral buildup. Check for leaks periodically and address them promptly. Use a soft cloth and mild cleaner to maintain the finish of the fixtures.

Safety Precautions Always turn off the water supply before starting any work. Use appropriate tools and wear protective gear when necessary.

Troubleshooting Low Water Pressure: Check for clogged aerators or showerheads. Clean or replace as needed. Inconsistent Water Temperature: Ensure the valve is properly adjusted and that the water heater is functioning correctly. Leaks: Identify the source of the leak and tighten or replace the affected connections.

Warranty Information Refer to the warranty card included with the product for details on coverage and duration.

Contact Information For support or replacement parts, contact the manufacturer or retailer where you purchased the product.