# Walker Edison® furniture company

ITEM # : W52CCR
Assembly Instructions

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. **www.walkeredison.com**

Revised 03/2017

General Assembly Guidelines

I.   Ensure that all parts and hardware are available before beginning assembly.

II.   Follow each step carefully to ensure the proper assembly of this product.

III. Two people are recommended for ease in the assembly of this product.

IV.   The main types of hardware used to assemble this product are wood dowels, cam bolts and locks, bolts and screws.

V.   The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.

In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.

VI.   A Phillips head screwdriver is required for the assembly of this product.

VII. Power tools should not be used to assemble this product.

VIII. The hinges of this product can be adjusted three ways:

Horizontal   Forward and Back   Vertical

Parts List

1

2

2

3

4

10

11

5

Front

6

7

8

14

14

9

12

13

Hardware List

A		Ø6x30mm	Wooden dowel	32	pcs
B		Ø6x32mm	Cam bolt	26	pcs
C		Ø15x9.5mm	Cam lock	26	pcs
D			Handle	2	pcs
E		Ø9mmx5/32"x3/4"	Bolt	2	pcs
F			Shelf support pin	12	pcs
G			Hinge	4	pcs
H		Ø4x12	Large screw	16	pcs
J		Ø7x2.5x12mm	Screw	6	pcs
K			Sticker	26	pcs
L			Glue tube	2	pcs
M			Touch-up marker (Except Black or White)	1	pc

*The hardware quantities listed above are required for proper assembly.*
*Some extra hardware may also have been included.*

Step 1

2

5

Front

A

2

A

A

Insert dowels (A) into panels (2,5).

Step 2

B

3

A

B

4

A

B

14

A

B

14

A

A

A

Insert dowels (A) into panels (3,4) and slats (14). Screw cam bolts (B) into panels (3,4) and slats (14).

Step 3

Screw cam bolts (B) into top panel (1).

Step 4

Screw cam bolts (B) into bottom panel (9).

Step 5

Attach slat (14) to panel (3) using cam bolts and dowels as guides. Secure the two pieces together using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 6

Attach slat (14) to panel (4) using cam bolts and dowels as guides. Secure the two pieces together using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 7

Attach panels (3,4) to panel (5) using cam bolts and dowels as guides.

Step 8

Secure panel (3) to panel (5) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 9

Secure panel (4) to panel (5) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 10

Attach the panel assembly from the previous step to bottom panel (9) using cam bolts and dowels as guides.

Step 11

Secure panel (3) to bottom panel (9) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 12

Secure panel (4) to bottom panel (9) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 13

Carefully slide panels (2) into place using cam bolts and dowels as guides.

Step 14

Secure panels (2) to bottom panel (9) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 15

On opposite side of console, secure panels (2) to bottom panel (9) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 16

Carefully slide back panels (10,11) into place along back side of console. *Panels (10,11) will overlap slightly as shown in insert above.*

Step 17

11

J

10

Secure back panels (10,11) to the console using screws (J).

Step 18

1

Carefully fit top panel (1) into place using cam bolts and dowels as guides.

Step 19

Secure top panel (1) to panels (2,3) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 20

Secure top panel (1) to panels (2,4) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 21

On back side of console, secure top panel (1) to panels (2) using cam locks (C). Tighten cam locks (C) with a screwdriver.

Step 22

Cover all visible cam locks with stickers (K) as desired.

Step 23

Attach hinges (G) to doors (12,13) using screws (H).

Step 24

Attach doors (12,13) to the console using screws (H) at hinges (G). *See page 2 for specific instructions on how to adjust hinges so doors are aligned with console as desired.* Attach handles (D) to doors (12,13) using bolts (E).

Step 25

Insert shelf support pins (F) into console at desired shelf heights.

Step 26

Insert shelf support pins (F) into console at desired shelf heights.

Step 27

Carefully place shelves (6,7,8) into console. *Shelves (6,7,8) will rest on the shelf support pins.*

Step 28

Final Assembly