



HOOKER
— FURNITURE —

ASSEMBLY INSTRUCTION

Item: 5183-75300 Splat Back Arm Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Qty
A		SCREW	8# × 1-1/4"	4pcs
B		BOLT	Ø1/4" × 1-1/2"	2pcs
C		BOLT	Ø5/16" × 1-3/4"	1pc
D		BOLT	Ø5/16" × 3-1/2"	4pcs
E		BOLT	Ø5/16" × 12	4pcs
F		FLAT WASHER	Ø5/16" × 19 × 2	9pcs
G		FLAT WASHER	Ø1/4" × 12 × 1	2pcs
H		LOCK WASHER	Ø1/4" × 12 × 3	2pcs
I		LOCK WASHER	Ø5/16" × 12 × 3	9pcs
J		Allen Wrench	4mm	1pc
K		Wrench	12mm	1pc
L		Wood Caps	Ø13.5 × Ø9.5 × 10	2pcs

