

Peel and Stick

Wall Preparation

Fill in any holes with vinyl spackling compound. Allow time to dry and sand smooth

Wash walls with an all purpose cleaner

No priming needed

(Peel and Stick will adhere and look best on a bright white wall with a smooth texture and an egg-shell, semi-gloss or satin finish. Let paint cure for four weeks before applying wallcovering)

Textured Wall Options:

1. Use a broad knife to spread joint compound to desired smoothness. Let dry and clean as instructed above.
2. Sand to desired smoothness then clean as instructed above.
3. Prepare walls as instructed above. Hang lining paper with a heavy duty adhesive. Let dry and clean as instructed above

Installation Instructions

1. Start with a dry smooth, clean white wall.

(see 'Wall Preparation' for more details)

2. Gather supplies - measuring tape or ruler, cutting tool, pencil, scissors, leveler, and wallpaper smoother

3. Measure the paper width, mark that distance on the wall, and draw your 'plumb' line from that using the leveler

Double check your plumb line width all the way down. ALL future panels line up from this line

4. Lay two wallcovering panels out on floor to match the pattern

5. On your first 'starting' panel, peel back two feet of the sticker backing and cut it off using scissors

6. Hang the first panel, using the plumb line for guidance and your smoothing tool to push out air bubbles

7. Continue to peel the sticker back, adhere the paper to the wall, and smooth out air bubbles all the way down to the floor

8. Repeat with other panels until desired area is covered

(You can lift and adjust paper if needed for corrections)

9. Use your cutting tool to cut excess wallcovering from around window edges, molding, electrical sockets etc.

10. Enjoy your new decor!