

Assembly Instruction For 20101

Attach the glass and then secure by socket ring.

