

INSTALLATION INSTRUCTION

Vitrine - Exterior

WS-W32512, WS-W32516



MODERN FORMS
A WAC LIGHTING COMPANY

WARNING

IMPORTANT: NEVER attempt any work without shutting off the electricity.

- Read all instructions before installing.
- System is intended for installation by a qualified electrician in accordance with the National Electrical Code and local regulations.
- Go to the main fuse box, or circuit breaker. Place the main power switch in the "OFF" position and unscrew the fuse(s) or switch "OFF" the circuit breaker switch(es) that control the power to the fixture or room that you are working on.
- Place the wall switch in the "OFF" position.

CAUTION

- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to follow this instruction could invalidate the ETL/CETL listing of this fixture.
- CAUTION When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.

AVERTISSEMENT

IMPORTANT : Coupez l'électricité avant TOUTE manipulation.

- Lisez toutes les instructions avant d'installer.
- Système est destiné à être installé par un électricien qualifié en conformité avec le code national de l'électricité et les règlements locaux.
- Accédez au panneau central de disjoncteurs ou de fusibles de votre demeure et placez l'interrupteur principal en position d'arrêt (« OFF »).
- Placez l'interrupteur mural en position d'arrêt (« OFF »).

MISE EN GARDE

- Toutes les pièces doivent être utilisées tel qu'il est indiqué dans ces instructions. Ne remplacez pas les pièces, n'en laissez pas de côté et ne les utilisez pas si elles sont usées ou brisées. Le non-respect de ces instructions peut annuler l'homologation ETL/CETL du luminaire. MISE EN GARDE Ors de la manipulation de l'appareil, ne pas appliquer de pression à la LED, tenir l'appareil par la seule base.

ADVERTENCIA

IMPORTANTE: NUNCA intente hacer trabajos sin desconectar el suministro eléctrico.

- Lea y comprenda todas las instrucciones e ilustraciones por completo antes de proceder con el ensamblaje e instalación de esta lámpara.
- Sistema está diseñado para ser instalado por un electricista calificado, de acuerdo con el código eléctrico nacional y las normas locales.
- Diríjase a la caja de fusibles o a la caja del interruptor de circuito principal en su hogar. Coloque el interruptor de alimentación principal en la posición "OFF" (APAGADO).
- Coloque el interruptor de la pared en la posición "OFF" (APAGADO).

PRECAUCIÓN

- Todas las piezas deben usarse como lo indican estas instrucciones. No reemplace las piezas, no omita piezas durante la instalación ni utilice piezas gastadas o rotas. El incumplimiento de esta indicación podría invalidar la calificación ETL/CETL esta lámpara. PRECAUCIÓN Al manipular el aparato, no aplique presión a los LED, mantenga el aparato en la base sólo.

HARDWARE

E1



Screw
Qty: 1pc

F1



Glass Holder
Qty: 1pc

G1



Screw
Qty: 1pc

H1



Mounting
Screw
Qty: 4pc +
1 extra

I1



Gasket
Qty: 4pc +
1 extra

J1



Wood
Screw
Qty: 2pc

K1



Junction
Box Screw
Qty: 2pc +
1 extra

L1



P3 Wire
Connector
Qty: 3pc

M1



Plastic
Anchor
Qty: 2pc

Modern Forms

www.modernforms.com

Phone (800) 526.2588 • Fax (800) 526.2585

Headquarters/Eastern Distribution Center

44 Harbor Park Drive • Port Washington, NY 11050

Phone (516) 515.5000 • Fax (516) 515.5050

Western Distribution Center

1750 Archibald Ave • Ontario, CA 91761

Phone (800) 526.2588 • Fax (800) 526.2585



INSTALLATION INSTRUCTION


Vitrine - Exterior

WS-W32512, WS-W32516



MODERN FORMS
A WAC LIGHTING COMPANY

Fig.1



Driver Technology Upgraded
No Driver Required
(Please direct wire with 120V AC)

PREPARATION

- Shut off the power at the circuit breaker and remove existing fixture, including the mounting hardware.
- Carefully unpack your new fixture and lay out all the parts on a clear area. Be careful not to lose any small parts necessary for installation.

MOUNTING THE FIXTURE (FIG. 1)

1. Position the mounting plate (B1) on the wall, mark the location of the key hole. Pre-drill the holes for plastic anchors (M1) and insert the plastic anchors (M1) into the wall.
2. Drill holes in the wall aligned with the key-hole location in the mounting plate (B1) insert plastic anchors (M1) into wall holes. Insert wood screws (J1) into anchors leaving enough length to hang mounting plate (B1).
3. Loose the mounting screw (E1) and put ring to the back plate with screw (G1) and put the glass (D1) in to the fixture and screw with the glass holder (F1) and screw (E1) safety.
4. Insert the wood screws (J1) into the plastic anchors (M1). From the key hole (A1) .Tighten the mounting plate (B1) to the wall.
5. Secure the mounting plate (B1) to the junction, box (N1) using junction box screws (K1). The side of the mounting plate marked "GND" must face out

CONNECTING THE WIRES (FIG. 2)

6. Making sure that all wire connectors (L1) are secured. If your outlet box has a green or bare copper ground wire, connect the fixture's ground wire to it. Otherwise. Connect the fixture's ground wire directly to the back plate using the green/ ground screw (C1) provided. After wires are connected. Tuck them carefully inside the junction box.
7. Put the fixture onto the mounting plate(B1) and secure with mounting screws (H1) and gasket (I1).


COMPLETING THE INSTALLATION (FIG. 3)

8. To prevent moisture from entering the outlet box and causing a short, use clear caulking (i.e. indoor/outdoor silicone sealant) to outline the outside of fixture back plate where it meets the wall. Leave a space at the bottom to allow moisture to escape (**Fig.3**).

Fig.2 Wiring

	Fixture Wires Black or Smooth	House Wires Black (Hot)
	Fixture Wires White or Ribbed	House Wires White (Neutral)
	Fixture Wires Bare wire (Ground)	House Wires Green or Bare Copper (Ground)

Fig.3 Sealing



Modern Forms
www.modernforms.com
Phone (800) 526.2588 • Fax (800) 526.2585

Headquarters/Eastern Distribution Center
44 Harbor Park Drive • Port Washington, NY 11050
Phone (516) 515.5000 • Fax (516) 515.5050

Western Distribution Center
1750 Archibald Ave • Ontario, CA 91761
Phone (800) 526.2588 • Fax (800) 526.2585

