

Tools Required: Fisheed screwiriver, Philips screwiriver, plans, wire cutters, wire strippers, electrical tape, safety glasses. Light Scarce: (1) 120V LED \*\*W DBINABLE (4000K).

Estimated Assumbly Time: 15-30 minutes

Preparation: Identity and inspect all parts before beginning translation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or deregged, do not attempt to assemble, install, or operate the totale. Context customer service for replacement parts.

## **▲ Warnings and Cautions**

Turn off electricity at circuit breaker or main fuse box before installation. Consult a floraged electricism if in doubt.

These instructions are provided for your safety, it is very important you read them completely before installing the focuse.

We strongly recommend that a floraged, professional electricism perform the headure.

Discovered future from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.



