

INSTALLATION INSTRUCTIONS

THEFT PROOF MIRROR SERIES - SURFACE MOUNTED | SHATTER RESISTANT

Product Information

Theft Proof Mirror Features:

- 1/8" thick shatter resistant acrylic mirror
- Theft Resistant Channel Framed Mirror



- ** Professional Installation is recommended to insure proper installation.
- **Please do not stand your mirror on end while unboxing. Lie the wall mirror down mirror side up prior to installation. Set on a clean surface, like a towel or carpet to avoid damage.
- ** Prior to discarding the packaging, locate hardware and screws where applicable.

Installation Steps

- 1. Each TPMA comes with a paper template for installation assistance. Tape the paper template on the wall where you would like to install the mirror.
- 2. Pre drill the marked holes on the paper. Insert screws and leave 1/8" of space for the mirror to slide onto the screw heads. (Additional equipment may be needed to complete installation.
- 3. ***STOP*.** Before sliding your mirror onto the screw heads. Make sure it is level and where you want it to be. Once you slide the mirror onto the screw heads the mirror will lock into place. There will be no way to remove the mirror from the wall without damaging it.
- 4. Slide the mirror into the locked position.

NOTICE:

- 1. Do not install mirror with damaged or broken glass. Contact the point of sale for further instructions on replacements.
- The installation instructions provided are for typical drywall/wood stud type walls. Additional hardware may/will be required for different wall types. Always make sure you adequately brace the mirror for secure installation. Do not screw directly into drywall without proper bracing.

