

Assembly Instruction For21500

- 1. Secure hex nut 3 into the nipple
- 2. Attached the nipple into the coupler, then secured by the hex nut2
- 3. Put the metal washer, rubber washer and the glass on the nipple, then seucred by the glass holder, hex nut and finial

