



Specifcation & Installation Guide

Features

Package Dimension

 Classic wavy design with high glossy paint. Soft-closing drawer. Compatible ceramic basins or artificial stone basins. Compatible matching mirror, medicine cabinet or LED mirror, medicine cabinet. Full extension drawers. Easy installation 	 14-61/64" x 12-61/64" x 50-19/32" 24 26-3/8" x 20-55/64" x 20-43/64" 30" 32-9/32" x 20-55/64" x 20-43/64" 36" 38-3/16" x 20-55/64" x 20-43/64"
Colors / Finishes	Gross Weight
Glossy White - 01	12" 43 LBS
	24" 45 LBS
	30" 52 LBS
	36" 58 LBS

Sink Top Options

Vanities	Ceramic basin	Artificial stone basin
S8008-12		
V8008-24	C04 2418	A10 2418 25
V8008-30	C04 3018	A10 3018 25
V8008-36	C04 3618	A10 3618 25
	S8008-12 V8008-24 V8008-30	S8008-12 V8008-24 C04 2418 V8008-30 C04 3018



Specifcation & Installation Guide



35-1/4 X 17-15/16" X 17-11/16 "

30"

29-5/16" X 17-15/16" X 17-11/16 "













Specifcation & Installation Guide

	Hardware			Tools (not includes)
No.		Draw	Qty	
А	White rubber plug (Ø6mm)	T	2pcs	
В	Screws (Ø4 x 68mm)		2pcs	
С	Stainless steel cover	00	2pcs	
D	Green rubber plug		6pcs	
E	Screw	Statutes.	6pcs	

Wall Preparation

 The typical dimensions shown will result in vanity cabinet height of 32-3/4"(831mm).Depending on the sinks selected, the total height will vary from 33-1/2"(850mm)35-1/4(895mm).If an alternate height is desired, adjust the rough-in and backing material heights using the dimensions provided.





Specifcation & Installation Guide



Draw a punched position on the wall with a pencil.



STEP 2

Drill the holes with suitable drill-bits base on different condition of the wall. Use a hammer to knock the white expansion rubber plug into the upper hole, and knock the green rubber plug into the three lower hole , align the hole in the wall and lock the leveling bracket to the wall with screws.

STEP 3

Hang the cabinet.(As the picture shows.)



Specifcation & Installation Guide



Secure the vanity onto the wall with screws.



Install sink top with silicone.



Finish.





PARIS Wall Side Cabinet

Specifcation & Installation Guide

1. Measure the wall-hung board and mark down the holes on the wall.

2.Drill the holes with suitable drill-bits base on different condition of the wall.

3.Use a hammer to knock the green expansion rubber plug into the hole.

Screw the 45 degree wall-hung panel onto the





STEP 2

wall.

Put up the back top panel of side vanity on the 45 degree wall-hung panel . Finished.



Blossom Kitchen & Bath Supply Corporation (718)-366-0088 | sales@BlossomUS.com | www.BlossomUS.com

For clarification, please contact us at (718)-366-0088 or sales@BlossomUS.com All dimensions are approximate and subject to standard tolerance. Specifications subject to change without prior notice.