

# Maykke

[www.maykke.com](http://www.maykke.com)

## **Installation and Warranty Guide**



Wallpaper

NOTICE: Consult a professional if needed.

NOTICE: Do not change or modify the product in any way. Doing so may compromise the products structural integrity and will void the warranty.

NOTICE: Installation instructions must be followed. Any diversions from the installations may risk property damage and will void the warranty.

### IMPORTANT:

Observe all state and local building codes.

Carefully read all installation and care instructions before proceeding.

### What you need:

- Adhesive: white or colorless (we recommend using a white latex plus methyl cellulose)
- Tape Measure
- Wall Primer
- Clear Painters Tarp
- Utility Knife
- Painter's Tape
- Spackle (optional)
- Sandpaper (optional)
- Paint Roller Tray
- Pencil
- Paint Roller
- 8" plastic smoother
- Another person (We recommend at least two people for this job)

### Before Getting Started:

Inspect the paper to see assure there are no defects or imperfections in the paper. If any imperfections are found STOP and contact Maykke customer service immediately.

### Preparing the Wall:

Spackle and sand the wall to smooth any imperfections, then apply a coat of wallpaper primer.

Make sure that the wall is clean, smooth, dry and clear of any debris before continuing.

### **Lining up your design:**

Cut strips of wallpaper 4" longer than the wall it will be placed on. (this gives you room to line up your design and to move the paper if needed)

Arrange the wallpaper on the floor, lining up the designs (this will make installing quicker and easier than trying to do this on the wall). Once it is lined up, you can use the painters tape to gently tape the pieces together.

### **Installing the Wallpaper:**

Pour the Adhesive mix into the rolling pan (being sure to follow the manufactures instructions). Using a small paint roller apply the adhesive quickly and evenly to the wall paper.

Apply the paper one strip at a time, smoothing each onto the wall from the center outwards using the 8" plastic smoother. Sheets should be placed right next to each other being sure to not leave space between or to overlap.

Once a piece is on the wall you will have 10-15 minutes to make any adjustments. Be sure to carefully push any bubbles out towards the borders during this time and to trim the excess paper using the utility knife.

Wash off any excess glue using a damp sponge and continue to smooth the wall paper as you go.

**For warranty information please check [www.maykke.com](http://www.maykke.com).**

**For customer service concerns please call: [877.659.2858](tel:877.659.2858) or email: [support@maykke.com](mailto:support@maykke.com).**