

Assembly Instruction For 21311

Put the glass on the socket, then secured by the socket ring.

