



Assembly Instruction For 21560TWPN

1. Insert the bulb(D) into socket
2. Hang the crystal string(CRS21560PN-C),(CRS21560PN-I),
(CRS21560PN-H) to the metal ring(S)(R) by mix
3. Hang the crystal string(CRS21560PN-B),(CRS21560PN-G),
(CRS21560PN-F) to the metal ring(T)(Q) by mix
4. Hang the crystal string(CRS21560PN-A),(CRS21560PN-D),
(CRS21560PN-E) to the metal ring(P)(U) by mix

