



MODEL: 32119BS

PACKING DIAGRAM





AVAILABLE PART IS:
32119SHBS (SHADE)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS LAMP SHOULD TAKE APPROXIMATELY 15 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

THIS LAMP INCLUDE 32119BS AND 32119BSBOX2. 32119BS AND 32119BSBOX2 ARE SOLD SEPARATELY.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE BOX OF 32119BS: SOCKET RING, ARM-1 WITH SOCKET, ARM-2, POLE, (4) SMALL SCREWS, METAL PLATE, (2) METAL WASHERS, LARGE SCREW, SCREWDRIVER AND WRENCH.

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE BOX OF 32119BSBOX2: SHADE AND BASE.

TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

1. CAREFULLY ORGANIZE AND PLACE ALL PARTS ON A SMOOTH, FLAT SURFACE. LINE UP ALL OF THE PARTS ACCORDING TO THE ASSEMBLY DIAGRAM.

2. SECURE POLE AND METAL PLATE TO TOP OF BASE WITH (2) METAL WASHERS AND LARGE SCREW. (WRENCH INCLUDED)

IMPORTANT: WHEN PERFORMING NEXT STEP, BE SURE THE SMALL HOLES/CORD EXIT IN POLE IS ON THE OPPOSITE SIDE WITH THE RED DOT ON SIDE OF BASE.

3. INSERT THE PIN ON BOTTOM OF ARM-2 INTO HOLE IN POLE AND SECURE WITH (2) SMALL SCREWS. (SCREWDRIVER INCLUDED)

4. INSERT THE PIN ON BOTTOM OF ARM-1 INTO HOLE IN ARM-2 AND SECURE WITH (2) SMALL SCREWS. (SCREWDRIVER INCLUDED)

NOTE: PLEASE MAKE SURE THE SOCKET LINES UP WITH THE RED DOT ON SIDE OF THE BASE.

5. REMOVE THE SOCKET RING FROM SOCKET BY UNSCREWING THE SOCKET RING.

6. PLACE SHADE OVER SOCKET AND SECURE WITH SOCKET RING.

7. PRIOR TO INSTALLING THE BULB, PLEASE INSPECT SOCKET FOR SILICA PACKET. IF PACKET IS PRESENT, REMOVE AND THROW AWAY. DO NOT EXPOSE TO CHILDREN AND PETS.

8. INSTALL A 120V, 60HZ, 150 WATT MAX. MEDIUM BASE TYPE "A" 3-WAY BULB (NOT INCLUDED) INTO SOCKET. MAKE SURE THE BULB IS TIGHTLY SCREWED INTO THE SOCKET BASE TO ASSURE 3-WAY FUNCTION.

9. PLUG THE POWER CORD INTO AN OUTLET AND TURN ON AT SWITCH.

BULB REPLACEMENT

1. BEFORE REPLACING THE BULB, BE SURE THAT THE SHADE AND BULB ARE COOL AND LAMP IS UNPLUGGED.

2. UNSCREW EXISTING BULB FROM SOCKET AND REPLACE WITH A NEW BULB. PLUG POWER SUPPLY CORD BACK INTO OUTLET.

TROUBLE SHOOTING

1. IF YOUR LAMP DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.

2. IF LAMP STILL DOES NOT LIGHT, UNPLUG FROM OUTLET. CHECK THE BULB FOR A BROKEN FILAMENT. REPLACE BULB IF NECESSARY, PLUG IN LAMP AND TURN IT ON.

3. IF THE LAMP STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

