ASSEMBLY INSTRUCTIONS

Description: Waldorf Lounge Chair

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description			QTY	
P1	Back Metal Frame			1	
P2	Seat Metal Frame			1	
P3	Left Side Metal Frame			1	
P4	Right Side Metal Frame	\square		1	
P5	Back Cushion	E		1	
P6	Seat Cushion	B		1	
P7	Upholstery Arm Rests	M		2	
Hardware List					
Item	Descrip			QTY	
H1	Bolts Ø1/4" x1/2"L		0		8
H2	Bolts Ø1/4"x1-3/16"L		0		8
H3	Bolts Ø1/4"x1-1/2"L		0		6
H4	Bolts Ø1/4"x2-3/8" L		0	D	2
H5	Lock Washers Ø1/4"		9		4
H6	Flat Washers Ø1/4"*22mm		0		2
H7	Allen Wrench 1/4"		J		1
H8	Flat Washers Ø1/4"*16mm		0		2



DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:

Step 1. Assemble the lounge chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the seat metal frame (P2) to the back metal frame (P1) using bolts (H2). Loosely tighten by Allen wrench (H7).



Step 2. Place left side metal frame (P3) and right side metal frame (P4) to seat metal frame (P2) and the back metal frame (P1), aligning insert the bar on side metal frames (P3 & P4) to the holes on the seat metal frame (P2), do not tighten at this time.



Step 3.

- 1) Attach left side metal frame (P3) and right side metal frame (P4) to seat metal frame (P2) using bolts (H1).
- 2) Attach left side metal frame (P3) and right side metal frame (P4) to the back metal frame (P1) using bolts (H3).3) Securely tighten all bolts by Allen wrench (H7).



Step 4. Open bottom covering and attach the seat cushion (P6) to the back cushion (P5) using bolt (H4) as shown below. Securely tighten all bolts by Allen wrench (H7).



Page 2 of 3

