AVOCA 3 SWING/DAYBED ASSEMBLY INSTRUCTIONS

- Before you start, here is some helpful advice
- 1. We suggest you spend a short time reading through this leaflet and follow the simple step-by-step assembly instructions.
- 2. Do not discard any cartons until you have checked all parts and fitting packs are available.
- 3. Assemble this product on a flat surface. Two people require for this product assembly.
- 4. Do not fasten any bolts and screws until all parts have completely assembled.
- 5. Discard any extra fittings. Keep wrenches out of reach to children.
- 6. Retain Assembly Instruction for future reference. Fittings should regularly be checked for tightness.
- 7. Children should not play on this furniture. Adult supervision is recommended if children used.



8T 1	CODE	SEAT DECK ASSEMBLY FITTING	QTY
HARDWARE LIST PART	1	JCBC M6 x 60mm	20
	2	Barrel Nut M6 x 16mm 🕘 🕤	24
	3	Revert + Snap Pin	2
	4	Nylon Washer 💿	2
	5	JCBC M6 x 100mm	4

					_
	CODE	PARTS		QT	Ŷ
	А	Ba	ck Rest	1	
	В	Ba	ck Rest Side Rail	2	2
	С	Se	at Deck	' 1	
	D	Sea	at Deck Side Rail	2	2
	Е	Sic	de Assy (Chair)-Left	1	
	F	Side Assy (Chair)-Right			
ה ה ר	G	Seat Support Bar			2
РА	Н	Fro	ont Leg-Left	1	
	Ι	Front Leg-Right			
-	J	Back Leg-Left			
-	K Back Leg-Right				
-	L	Top Rail			
	М	Во	ttom Rail	1	
	N Side Rail			2	2
	0	Su	pport Bar	2)
			p Bar	2)
	Q	Са	nopy Supporter (Long)	2	
		Car	nopy Supporter (Short)-Left	1	
		Cai	nopy Supporter (Short)-Right	1	
	Т	Са	пору	≥ 1	
	CODE 'A' FRAME ASSEMBLY FITTING			QTY)
	DWARE LIST PART 2		JCBC M6 x 70mm	4	1
	IST	7	JCBC M6 x 50mm	4	1
	ARE L	8	Lock Nut M6	8	1
	NDW/	9	Flat Washer 0 13	8	
					-

10

JCBC M6 x 45mm

20

HARDWARE LIST PART 3	CODE	ASSEMBLY FITTING FOR PART 3&4	QTY
	11	Hex Head M12 X 60	2
	12	Hex Nut M12	2
	13	U Hook C	2
	14	Chain : Short 000000	2
	15	Chain : Long	2
	16	JCBB M8 X 60mm	4
	17	Hex Nut M8	8
	18	Thick Nylon Washer	8
	19	M6 QM 🎾	4
	20	Lock Nut M6	4

	CODE	ASSEMBLY FITTING FOR PART 3&4		
HARDWARE LIST PART 4	21	JCBC M6 X 60mm		8
	22	JCBC-W M7 X 50mr	n)	2
	23	Barrel Nut	80	8
	24	M19 Spanner	\sum	1
	25	M13 Spanner	\sum	1
	26	Allen Key		1
	27	M4 Allen Key		1
	28	Barrel Nut Tool		1
	29	M10 Spanner	\sum	1
				\square

PART 1 : Seat Deck Assembly



PART 2: A-Leg Assembly



Assembly Instruction For Part 3 & part 4

