

Assembly Instructions for Tourmaline Glass Sconce

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operations of the product and the hazards involved.

Please follow the steps and the diagram for assembling your SCONCE and make sure electricity is OFF during assembly.

You should have received: A: Fixture, B: Glass, C: Light Socket, D: Finial

1. Install A. Fixture with the C: Light sockets directionally up and down or perpendicular to the floor.
2. Then, remove the D: Finial by unscrewing it.
3. Line up the hole in the center of the glass over the metal nipple in the center of the sconce A: Fixture. The B: Glass should be open at the top and bottom and touching the walls on the sides (left and right).
4. Screw the D. Finial onto the nipple over the front of the glass. This will further secure the glass onto the A. Fixture.

IMPORTANT NOTE: **MAKE SURE TO SCREW THE RING ONTO THE GLASS SNUG, BUT NOT TIGHT.** The glass will need room to expand and contract with the heating and cooling of the bulb.

