

0069 Queen Bed

Assembly Instructions







0069 Queen Bed

Assembly Instructions

(D) Bolt the Bed Slats (P) to the Side Rail (J).







WI-1220





0069 Queen Bed

Assembly Instructions

