

HOW TO MEASURE FOR WINDOW BLINDS AND SHADES


IMPORTANT

PRODUCT WIDTH IS 1/4" LESS THAN THE WIDTH PROVIDED.

PLEASE PROVIDE EXACT WINDOW WIDTH, WE WILL MAKE PROPER ADJUSTMENT.
INSIDE WINDOW TREATMENTS HANG INSIDE THE WINDOW CASING.

IT'S IMPORTANT THAT YOUR WINDOW MEASUREMENTS -- ESPECIALLY THE WIDTH -- ARE AS EXACT AS POSSIBLE SO YOUR COVERING FITS AND WORKS PROPERLY.

INMOUNT



OUTMOUNT

