Numeral Install Instructions



1. Place number on wall where you would like to mount it.



2. Mark holes with a pencil.

3. Drill pilot holes with 1/16" drill bit to 3/4 of depth of screw.







4. Use appropriate screw head/bit to mount number to wall.