

BBL5033


ASSEMBLY & INSTALLATION GUIDE

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.



1. Attach chain (F) to top loop (G) on stem (J) by opening/closing end link of chain.
2. Feed wire through chain (F) and mounting loop (E).
3. Attach mounting strap (A) to ceiling outlet box with mounting screws (B).
4. Insert threaded nipple (C) into center hole of mounting strap (A) and thread one of hex nut onto the nipple using pliers until snug.
5. Slide canopy (D) over threaded section of (E). Attach chain mounting loop (E) with canopy (D) to thread nipple (C), thread another hex nut onto the nipple until tight.
6. Attach chain (F) with fixture to chain mounting loop (E) by opening/closing end link of chain.
7. Attach the bare copper ground wire from the fixture to the ground junction box wire (usually green or copper wire). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
8. Connect the neutral wire from the fixture (ridges molded wire) to the neutral wire from the junction box (usually white). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed.
9. Connect the hot wire from the fixture (smooth wire) to the hot wire (usually black) from the junction box.
10. Fasten each together with a plastic wire connector and wrap the connection with electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
11. Attach shade (P) to stem (J), slide shade spider on threaded section above washer (H), and secure by turning washer (H) in clockwise direction.
12. Screw rod (L) on bottom threaded nipple of part (K).
13. Insert light bulbs into sockets.
14. Remove finial (O) & flat washer (M) form rod (L). Slide flat washer (M), followed with acrylic diffuser (N) over threaded rod at lower section of rod (L), secure with finial (O).