Progressive® ASSEMBLY INSTRUCTION Item No: D878-64 / D879-64

Description: COUNTER STOOL



IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

Each chair

PARTS LIST			
NO.	DESCRIPTION	QTY.	
1	LEG MEMBER	2 PCS	
2	WOODEN SEAT	1 PC	
3	SHORT STRETCHER	2 PCS	
4	LONG STRETCHER	2 PCS	

HARDWARE LIST				
NO.	DESCRIPTION		QTY.	
A	ALLEN KEY M4 X 63 MM		1 PC	
В	JCBC/W SCREW M7 X 50 MM	(a))))))))))	4 PCS	
С	PH CBS #8 1 1/2		4 PCS	
D	PH CBS #8 1 1/4	()	4 PCS	
Е	DOWEL PINS M8 X 30MM		2 PCS	
F	WOOD BUTTON Ø14.5 X 9M	IM 🔾	4 PCS	

STEP 1



