Assembly Instruction For 9012



1.Place the glass on the socket, then secured by metal cap and socket ring2. The another 1PC as same the step 1

