

LIBERTY FURNITURE

ASSEMBLY INSTRUCTION

0

607/507-BR13/BR14/BR90 ITEM# 607/507-BR15/BR16/BR90 __ DESCRIPTION Panel Bed

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below. Assembly steps:

Step 1. Assemble the Cross bar (G) to the Posts (L/R) (B) using Wood dowel (j), Bolt (e), spring washer (g), flat washer (h) and allen key (i). Step 2. Assemble the Posts (B) to the Headboard (A) using Bolt (f), spring washer (g), flat washer (h) and allen key (i).

Step 3. Assemble the Side rails (D) to the Posts (B) and Footboard (C) using set-screw (a), washer (b), nut (c) and wrench (d).

Step 4. Attach the Slat support (F) to the Slat (E) Step 5. Screw slats (E) in place using screws (k).

Step 1

NO. SKETCH DESCRIPTION	Q'TY
~^	211
A Headboard	1pc
B Post (L/R)	2pcs
C Footboard	1pc
D Side Rails	2pcs

NO.	SKETCH	HARDWARE	QT
а	dinnininininininininininininininininini	5/16"x18x2-3/4"	8pcs
b	<u> </u>		8pcs
С	®	5/16"	8pcs
d	2=	12 mm	1pc
е		5/16"x18x1-3/4	2pcs
f		5/16"x18x1-1/2	6pcs
g	0	5/16"x12 mm	8pcs

5/16"x19 mm

HARDWARE LIST

