

## Assembly Instruction For 87632, 87634,87574

- 1. Turn breaker off for circuit on outlet where fixture is to be installed.
- 2. Remove mounting bracket from fixture and install to electrical box.
- 3. Wire fixture to wires in outlet box. Green wire is for Ground.
- 4. Install fixture to bracket and tighten finials in the canopy to secure.
- 5. Re-install lens to fixture turning clockwise

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

Lutron MACL-153M Lutron DVL-153P

Lutron SCL-153P Leviton IPL06-10Z

Leviton 6674-POW

Due to the inrush current, wattage should not exceed 150 watts of product for a 600 watt dimmer.

