

Assembly Instruction For 20036

Assembly Instructions

- 1. Rotate the bent tubes (A) to the correct position .
- 2. Loosen the socket ring (E) from the socket (B).
- 3. Fit the shade (C) and the ring (D) onto the socket (B) then tighten with the socket ring (E).

Electrical Wiring

With wire connectors, connect powercords from outlet box to fixture.

- Smooth/ Black wire to Black wire
- Ribbed/ White wire to White wire
- Green to Ground

Please consult a qualified Electrician if you are not familiar with electrical wiring.

