Note:Styte may vary by model



Before Installation

A . Make sure you have all necessary parts by checking the diaggram and parts list.

B. Tum off the hot and cold water supply at the angle stops and tum on the old faucet to release any built up pressure. Remove existing faucet. Clean sink or countertop in preparation for new faucet.

C. Shut off angle stops.

D. Pre-drilled size requirement: 1-3/8" (min)-1-1/2" (max) Max countertop thickness without deck plate: 1-1/2" (1hole install) Max countertop thickness with deck plate: 1" (1, 2or 3 hole install)



Diagram and Parts List Note:Style may vary by model.



Right of product modification such as dimension without notice is reserved.

3 Hole Bathroom Faucet

Note:Styte may vary by model

				•	•	
Slide the washe(O-ring) to faucet base. Insert the new faucet through sink.	Prepare to install receiver. Install washer on	l the undemeath nut and tee joint.	Insert rubber washer, then insert trident joint.Tighten trident and align with valve.	Tighten coupling nut and insert trident.	Insert hot and cold water handles through the hole.	Put on fitting access- ories in correct order.
			3	4	5	
Tighten the handles. with hot an Tum on Wat			ghten the hoses old Water supplies. supplies,tum the hehot and cold nute.	Connect and tighten the hoses	Inspection installation results: 1.Check to make sure that all of the connection has been tightened. Make sure the handle in the closed position.	
		8		9	the leaking interface. Washing instructions Apply to all the processed surface With neutral soap water to clean the cloth to wipe the surface with many ammonia. household cleanser. and wil avoid by all means use.	plating surface.then use a clean soft cleaner. Lavatory spirit,etc.such as

Right of product modification such as dimension without notice is reserved.