ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL# LV00809

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, Identify and count all parts and metal hardware. Compare with all parts listed to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.



| Hardware List | | | |
|---------------|----------|-----------------------|-------|
| 1 | H | Bolt Ø5/16"*3-1/2" | 3 pcs |
| 2 | Ø | Spring washer Ø5/16" | 3 pcs |
| 3 | 0 | Flat Washer Ø5/16"x23 | 6 pcs |
| 4 | 6 | Screw nut Ø5/16" | 3 pcs |
| 5 | ~ | Wrench Ø5/16"x12mm | 1 pc |

PART LIST:



How to assemble & Steps

Note: Please press both sides down simultaneously when assembling the back.

