





Assembly Instructions







Assemble the Side Rail (F) to the Head / Footboard.





9 Bolt & screw the Bed Slats (J) to the Side Rail (F).



Fit the Top Bar- Long (E) on top of the Head / Footboard Post.

