

Thank you for purchasing your heirloom quality furniture from Montana Woodworks*. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at: cs@montanawoodworks.com

Tools Needed: 9/16" Wrench or Socket

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Table Top Assembly, (4) Legs

Hardware List: (4) 5" Lag Bolts, (4) Washers

Assembly Instructions:

Step 1. Remove components from shipping boxes. You may lay the cardboard on the floor to prevent marring of finish.

Step 2. Lay table top face down on a soft, non-marring surface.

Step 3. Place one leg in the corner of the table top and align with pre-drilled hole.

Step 4. Insert and tighten a lag bolt and washer until snug. DO NOT OVERTIGHTEN!

Step 5. Repeat for remaining three legs.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. if the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.