## Assembly instruction

1.Get all components ready.



2. Screw Cap B down about half inch.



3. Attach Shade C to Light Assembly A by inserting the cut-out of the center shade washer to the threaded tubing and tighten it by screw Cap B up.

