



MAKE SURE THE LETTERS
MATCH BEFORE ASSEMBLING
NEED ASSEMBLY ASSISTANCE?
CALL US AT 866-814-8325

Assembly Instruction

INSTRUCTION DE MONTAGE
MONTAGEANLEITUNG
SAMLEVEJLEDNING



*Make sure to use Gorilla Glue (Not Included)
on all wood joints before assembly*

Code

Am44

Hardware



Custom Bolt 40 mm (2 Pcs)

Tool



Socket Wrench 4mm Ht

Total Section