## **ASSEMBLY INSTRUCTIONS**

- 1. Carefully lay all parts out in a line on a flat surface. Be careful not to pull the center cord heavily as a bad connection may result.
- 2. Begin the assembly of the lamp at the base and proceed upward to the shade.
- 3. Screw the lower stem onto the base clockwise until secure.
- 4. Assemble the next section of middle stem by screw onto top of lower stem until secure.
- 5. Turn the upper stem counter clockwise several times in order to avoid damage to the center cord and then screw the upper stem clockwise onto the middle stem.
- 6. Screw the threaded pipe onto the top of lamp holder base.
- 7. Attach the shade onto the threaded pipe and secure with finial (DO NOT OVERTIGHTEN)
- 8. Install bulbs.

**CAUTION** - Refer to the wattage caution label located near the lamp holder for recommended maximum wattage-do not exceeds recommended wattage.

**WARNING** - Do not attempt to replace the bulb while the lamp is plugged into a wall receptacle.

9. Insert plug into wall receptacle.



- **Note:** 1. The above diagram illustrates the installation of your new luminaire. This is a representative drawing and is not intended to match the style of your luminaire.
  - 2. This stained glass product has been protected with mineral oil as part of the finishing process. Please use a soft dry cloth to remove any excess oil.

## **IMPORTANT SAFETY INSTRUCTIONS**

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

MADE IN CHINA