



ITEM NO.NSJY0539

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTAINANCE AND WARNING

- 1.Keep furniture away from heat sources.
- 2.Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- 3.Do not place furniture under direct sunlight, material will possibly fade over time.
- 4.Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
- 5.Do not write on furniture that is not protectedby a padded barrier.
- 6.Not for commercial use, only for residential use.



EXPLOSIVE VIEW



PARTS LIST 1



HARDWARE LIST



TOOL LIST





HARDWARE SPARE LIST



1. install leg (J) on of bottom panel B, ensure the corresponding holes are aligned and fix with bolt #7, then tighten the bolt with an Allen key #13.



1.Insert part (F) into part (E),make sure all holes aligned and fix with screw #4 then tighten the screw with screwdriver #14.



1.Insert panel (E/F/G) into panel (C/D),make sure all holes aligned and then tighten it with allen key #13 as picture show.





1.Insert preassembled step 4 into the corresponding hole of bottom panel (B), make sure all holes aligned and use allen key #13 to tighten it as picture show.



STEP-5

1.insert back panel(I) into the groove of preassembled step 4 ,make sure all holes aligned and use screw#6 to attach them , tighten screw #6 with screwdriver#14.





STEP-6

1.insert part (H) into the preassembled step 5,make sure all holes aligned and use screw#4 to attach them , tighten screw #4 with screwdriver#14.



1.insert part #5 into the preassembled step 6,make sure all holes aligned and use screw #2 to attach them , tighten screw #2with screwdriver#14.



1.Insert the top panel (A) into the corresponding holes in the pre-assembly step 7, make sure all the holes line up and tighten it with 13 Allen key as shown in the picture.



M6

x1





STEP-10

1.Connect part (L&M) to part (O) using screw #4 and tighten it with screwdriver #14.

2.slide in the part (N) into the groove in part (L&M). make sure they are also in groove in part (O).



STEP-11

1.Connect the (O) and (L&M) using screw #4 , and tighten it with screwdriver #14.

2.Install handle #3 to panel (O) using bolt #1 and tighten it with screwdriver #14.





STEP-13

Use screw #12 to attach plastic bracket #15 to panel (A),make sure all holes aligned and tighten screw #12 with screwdriver #14



STEP-14



1. Mark the position on the wall, that corresponds to the location of bracket #15 on the panel (A); Drill and insert the expandable screw #8 by hammer.

2. Assemble the bracket #15 to the wall. Align the hole in the bracket #15 with the expandable screw #8,use screw #11 to attach it, tighten screw #11 with screwdriver #14.





3. Let the plastic belt #10 pass through bracket #9 and pull tightly.



WARRANTY

- 1.We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
- 2.We provide 30 days warranty starting from the time you receive the item.Each customer must provide a record of their order such as the order number,or item receipt for any items that are out of the warranty period you may also still receive.
- 3.Replacement parts by purchasing them with our company if they are available.

Are you having difficulty With assembly?Missing parts? Please send email with your order No to **customerservice@hulalahome.com** For return,please check the return policy with the retailer or market place you bought from.

> Appreciate your purchasing from us. Pop up your life by our furniture piece!