

Assembly Instruction For12206

- 1.Attached the top arm on the nipple 1 then secure by tube.
- 2.Attached the cap on the nipple 2 then secure by finial.
- 3.Attached the glass on the socket then secure by socket ring.

