



1. Drill the holes after measuring the location of installation holes.
2. Using a hammer to insert the anchor onto the solid wall.
3. Putting the base plate over the anchor, then insert the screws with a screwdriver.
4. Attach the post onto the base plate.
5. Using a hex wrench to tighten the screws to finish the installation.