

# Composite Appliques & Onlays

## SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear proper protective gear.

Follow fixture, power tools, paint manufacturers' instructions, and users manuals.

Use common sense and follow good construction practices.

### TOOL & MATERIAL CHECKLIST

- construction adhesive
- rag

### SPECIAL INSTRUCTIONS AND NOTES

- It is highly recommended that you paint/finish our appliques before you install them. Once installed, you can apply any necessary touch up paint/finish.
- Clean installation surface and back of appliques of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the applique are completely dry before attempting installation.
- Measure and mark the location where the applique is going to be installed.

### STEP BY STEP INSTRUCTIONS

1. Lay the applique face down on a soft surface that will not scratch/dent the applique detail.
2. Apply small bead of construction adhesive all the way around the back edge of the applique.
3. When pressing the applique up against the surface, some adhesive may seep out.
4. Wipe away excess adhesive around the applique with finger or rag.

### EXAMPLE INSTALLATION DIAGRAMS

