

ASSEMBLY INSTUCTIONS

72014001 - Lakewood Side Table 3Drw.

STEPS:-

1. Unpack the both Iron Pipe Frame and Wooden Top.
2. Match all matching marks.
3. Screw Iron Pipe Legs at Back & Front with the help of LN Key (As per picture)



ASSEMBLED PRODUCT

