SYMMONS® Duro® the smart choice™

363DTB-18, 363DTB-24, 363RH, 363TB-18, 363TB-24, 363TP, 363TR, 363TS-22, 363-SD2 Accessory Suite

Operation & Maintenance Manual



Operation & Maintenance Manual			
Model Numbers		Specification	
 363DTB-18 363DTB-24 363RH 363TB-18 363TB-24 363TP 363TR 363TS-22 363-SD2 	18" Double Towel Bar 24" Double Towel Bar Robe Hook 18" Towel Bar 24" Towel Bar Toilet Paper Holder Towel Ring Towel Shelf with Bar Soap Basket	All premium accessories constructed from metal materials plated in standard polished chrome finish.	
		Compliance	
		For California Residents WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.	
Modifications		Warranty	
 Satin Nickel finish Note: Append appropriate -suffix to model number. 		Limited Lifetime - to the original end purchaser in consumer installations. 5 Years - for commercial installations. Refer to www.symmons.com/warranty for complete warranty information.	

Dimensions



363TB-18



363TB-24



363DTB-18



363DTB-24



363TS-22



Note: Dimensions subject to change without notice.

	Measurements				
Α	1-13/16", 46 mm				
В	2", 51 mm				
С	5-3/8", 137 mm				
D	4-1/8", 105 mm				
E	2-1/2", 64 mm				
BCDEFGH	6-7/8", 175 mm				
G	5-3/4", 146 mm				
Η	18", 457 mm				
l J	19-13/16", 503 mm				
	3-1/4", 82 mm				
Κ	24", 610 mm				
L	25-13/16", 656 mm				
Μ	5-3/8", 136 mm				
Ν	22", 559 mm				
0	23-13/16", 605 mm				
Ρ	4-3/4", 121 mm				
N O P Q R S T U	9-5/8", 244 mm				
R	3/8", 10 mm				
S	9", 228 mm				
Т	4-1/4", 108 mm				
U	2-3/8", 60 mm				
Replacement Parts					
D	escription	Part Number			
1	Mounting ardware Kit	RA-017			







Installation

- 1) Measure and mark centerlines for mounting bracket installation using dimensions on page 2.
- 2a) **Dry Wall Option:** Place mounting brackets into desired position. Using brackets as a guide, carefully drill 5/16" holes into wall. Remove brackets and install anchors.



Note:

363DTB-18, 363DTB-24, 363TB-18, 363TB-24, 363TS-22 only. Make sure both centerline marks are level.

Note:

For plaster walls 1/2" thick or less, insert toggle tool into toggle to secure behind wall prior to installing accessory trim.

4) Secure with set screw.

2b) **Stud Option:** Center bracket on centerline. Using brackets as a guide, carefully drill 3/16" holes into wall.



3) With mounting brackets in position, secure to wall using screws.



363-SD2 Only: Carefully drill 5/16" holes into wall and install anchors. Secure to wall using screws.



5) Hang top of accessory on mounting bracket. Lower into position.



Troubleshooting Chart

Problem	Cause	Solution
Finish is spotting.	Elements in water supply may cause water staining on finish.	Clean finished trim area with a soft cloth using mild soap and water or a non-abrasive cleaner and then quickly rinse with water.