Assembly Instruction For21507

 Place the shade frame on the socket, then secured by socket ring
Put the glass shade and rubber washer on

the shade frame, then secured by finial

MAXIM

