

Assembly Instruction

INSTRUCTION DE MONTAGE MONTAGEANLEITUNG SAMLEVEJLEDNING

MAKE SURE THE LETTERS MATCH BEFORE ASSEMBLING NEED ASSEMBLY ASSISTANCE? CALL US AT 866-814-8325

Code

SST 34


1



2




Hardware




BOLT 2,36' (8 Pcs)


3



4



Tool



Socket Wrench 4m

Total Section

4 Section

Make sure to use Gorilla Glue (Included) on all wood joints before assembly