

1

Take the product out of the bag



2

Snap the panels together, just align them so they match with the next panel



3

Hang the panels to the desired area using zip ties for installing on mesh wire or use concrete/drywall or stucco nails



4

Once hanged on the desired surface fix the product randomly

