

Traditional (non-pasted) Wall Preparation

Fill in any holes with vinyl spackling compound. Allow time to dry and sand smooth.

Wash walls with an all purpose cleaner

Prep walls with a one-step acrylic primer/sealer.

Textured Wall Options:

1. Use a broad knife to spread joint compound to desired smoothness. Let dry, clean and prime as instructed above.
2. Sand to desired smoothness then clean and prime as instructed above.
3. Prepare walls as instructed above. Hang lining paper with a heavy duty adhesive. Prime walls again with a one-step acrylic primer/sealer.