ASSEMBLY INSTRUCTIONS



Step1: Put The Part C At The Top Of Part A & B,Screw It With Part E*8,Not Tighten.

Step2: Put The Part D Between Part A and B, Screw It With Part E*4.

Step3:Tighten All Part E.

Step4:T The Part F Is The Whole Item.