

## Assembly Instruction For 9011

Place the glass on the socket, then secured by metal cap and socket ring

